

Your VorzAmp is fully charged, you can start using it immediately.

While charging please note the **direction** while inserting the micro USB into the amplifier carefully.

## Charging Procedures and FAQs for VorzAMP Pure II /Pure II+/Duo II

To charge your amplifier properly:

- Switch **OFF** Amplifier
- AC Charger output must be 5V DC minimum 1A or Notebook/computer USB to have minimum current of 1A

During the charging process:

- The Red LED should stay on continuously, it should not be blinking.

### FAQs

1	At the start of charging the amplifier the Red LED light is blinking	Charging rate is not optimal: <ul style="list-style-type: none"><li>• <u>Switch OFF</u> the amplifier</li><li>• AC charger is incorrect (current must be minimum 1A)</li><li>• USB port of Notebook/computer current too low (current must be minimum 1A)</li></ul>
2	Can the amplifier be playing and at the same time be charging?	<ul style="list-style-type: none"><li>• Yes, but the charging rate will be slow and the amplifier will not be able to be Fully Charged.</li><li>• The Red LED light will blink after 3h to 3.5h (switch OFF AC charger for 5 seconds and turn it ON again)</li><li>• If you need to charge and play the amplifier at the same time, first charge the amplifier for 1h before playing/using the amplifier.</li></ul>
3	How do I know the amplifier is Fully charged?	<ul style="list-style-type: none"><li>• During charging the Red LED light will turn OFF automatically. (~2.5h)</li></ul>
4.	After charging for more than 3h the Red LED starts blinking.	<ul style="list-style-type: none"><li>• The internal charging time has exceeded, switch Off the AC charger for a few seconds and turn On again.</li><li>• It is recommended that the amplifier is switched OFF while charging, to give it a quick and full charge.</li></ul>